



Shadesail Layout Plan For 5 x 5 x 5 Metre Triangle.

Posts to be set outside the line of the triangle so there is at least 300mm between the eyebolt and the shadesail. This is to allow tensioning of the sail. Eyebolts are best facing inwards toward the centre. Low columns to be set in the ground 700mm and High Column to be set in the ground 900mm. Holes to be a diameter of 450mm. Columns should be set using a concrete mix 20mpa and left to set for 1 week before tensioning shadesail.

When fitting sail, extend turnbuckles fully, fit D-shackle to eyebolt and turnbuckle then hook through triangle in sail. Tighten internal cable in sail and lock off with rope grip. Tighten turnbuckles and lock until sail is taught.